


# **Dragonfly Surface Mount Adaptor Installation Instructions**

## **Compatible products**

The surface mount kit can be used with the following products:

	Display	Adaptor kit part number
	<ul><li>Dragonfly-4 DV</li><li>Dragonfly-4 DVS</li><li>Dragonfly-4 Pro</li></ul>	A80366
(Sequentitus	<ul><li>Dragonfly-5 DV</li><li>Dragonfly-5 DVS</li><li>Dragonfly-5 M</li><li>Dragonfly-5 Pro</li></ul>	A80366
	Dragonfly-7 Pro	A80347

### Parts supplied



- 1. Adaptor Bezel
- Adaptor Clamp Fixings (M2,5x8 pozi pan head flanged) A80347 = x 14; A80366 = x 12
- 3. Adaptor Clamp
- 4. Front Seal
- Adaptor Fixings (M4x40 pozi pan head bolt, washer, spring washer and nut)

- 6. Surface Mount Adaptor
- 7. Rear Gasket


### Warning: Marine-grade sealant

Only use non-acetate based marine-grade sealants. Using an acetate based sealant can cause damage to plastic parts.

# Surface mounting

Before mounting ensure that you have:

- selected a suitable location (a clear, flat area with suitable clearance behind the panel is required).
- installed the transducer and routed the power / transducer cable to the selected location.
- 1. Fix the supplied mounting template to the selected location, using masking or self-adhesive tape.
- Using a suitable hole cutting saw, make a hole in each corner of the cut-out area.
- 3. Using a suitable saw, cut along the inside edge of the cut-out
- 4. Ensure that the Surface Mount Adaptor fits into the removed area and then file around the rough edge until smooth.
- Drill 4 holes as indicated on the template to accept the adaptor's fixings.
- Remove the backing from the Rear Gasket and place onto the back of the Surface Mount Adaptor, pressing firmly onto the flange.
- Ensuring correct orientation, place the Surface Mount Adaptor into the prepared hole and secure using the Adaptor Fixings (Bolt, washer, spring washer and nut) provided.




**Note:** The supplied Rear Gasket provides a seal between the Surface Mount Adaptor and a suitably flat and stiff mounting surface or binnacle. The Rear Gasket should be used in all installations. It may also be necessary to use a marine-grade sealant, if the mounting surface or binnacle is not entirely flat and stiff or has a rough surface finish.

- 8. Feed the cable through the prepared hole and connect to the display.
- If required, insert your Cartography chart card or MicroSD card into the card reader.


**Note:** Once surface mounted, the MicroSD card reader is not easily accessible.

- Ensure that the card reader's cover is correctly closed to prevent water ingress.
- Place the display into the Surface Mount Adaptor and hold in position.

Document number: 87259-1 Date: 01-2016




- 12. Attach the Front Seal to the Surface Mount Adaptor, ensuring it is correctly seated all the way around.
- 13. Place the Adaptor Clamp over the Front Seal, ensuring that the locating hole in the Adaptor Clamp lines up with the locating pin on the Surface Mount Adaptor.
- 14. Secure the Adaptor Clamp using the supplied fixings (screws), ensuring that they are all finger tight.




15. Using the sequence shown below for your adaptor, tighten the screws to a torque of 3.5 to 4.0 Kgf.cm.


### Dragonfly-4 and Dragonfly-5 (A80366) (12 x screws)



Dragonfly-7 Pro (A80347) (14 x screws)



16. Attach the Adaptor Bezel.



An optional suncover is also available for surface mount installations:

- A80367 = Dragonfly-4 and 5
- A80348 = Dragonfly-7 Pro