


SEAVIEW

ELEVATE YOUR ELECTRONICS



INSTALLATION INSTRUCTIONS

For Seaview Light Bars:


LTB-SF, LTB-SF2

Refer to website for most up to
date instructions and videos.


WWW.SEAVIEWGLOBAL.COM

PARTS INCLUDED


LTB-SF PARTS



X1




X1




X1 Part #SLADAPT3




X6




X4




X8




X4



X4




X6




X4


LTB-SF2 PARTS




X1




X1 Part #SVFA3




X4




X8




X4



X6




X4




X4

TOOLS NEEDED




1

Install your light, adapter or box onto the light bar by following the instructions that came with the optional accessory.




2

Insert the four nuts into the adapter plate. This has most likely been done for you.




3A

Using a philips head screwdriver screw in the six #12x1" screws to secure the camera to the adapter plate.
(For #LTB-SF2 only)




3B

Secure the camera or search light assembly to the light bar using the four 1/4-20x1" bolts and nylon shoulder washers.




4A

Using a philips head screwdriver screw in the six M6 - 16mm bolts to secure the camera to the adapter plate. **(For #LTB-SF only)**




4B

Secure the camera or search light assembly to the light bar using the four 1/4-20x1" bolts and nylon shoulder washers.




5

Insert the light bar into the light bar hole located on the back of the Seaview mount.



6A Using the four 5/16x1" bolts and nylon shoulder washers, secure the light bar by bolting it to the top plate.



6B When using the Seaview #SP1-MOD or #SP2-MOD Spreader Kits use the 5/16x2-1/2" bolts.

The background of the entire page is a light gray topographic map with white contour lines. The lines are irregular and wavy, creating a sense of depth and movement. The map covers the entire area, with the text elements overlaid on it.

SEAVIEW///

ELEVATE YOUR ELECTRONICS

SEAVIEW///

Tel: 800-655-7922
www.seaviewglobal.com

EUROPEAN OFFICE

Tel: +33 4 94 53 27 70
www.seaviewprogress.com

4-010719